

Dear Customer,

This Quick Start Guide is enclosed with detailed dishwasher Operating Instructions. Before using the appliance carefully read the Operating Instructions, especially guidelines for safe use.

Before plugging your dishwasher into the mains power, remove the safety packaging. Do not start the dishwasher before it is properly set up.

1 Turn on the appliance

- Close the dishwasher door, press the on/off button. Power indicator will be on.

2 Dispense detergent

- Press the latch to open the detergent dispenser.
- Add detergent to the dispenser.

3 Check the special salt level

- Add special salt to the dispenser when the corresponding indicator on the control panel comes on.

4 Load the dishes

- Remove food leftovers from the dishes
- Place the dishes in the baskets according to loading guidelines.
- It is recommended to load the lower basket first, then the upper basket.

5 Select the wash programme

- Press the button to select the desired program, the corresponding indicator will light up.

6 Start your dishwasher

- Close the dishwasher door.
- The dishwasher will start a wash programme.

7 Turn off the appliance



- Turn the appliance off using the On/Off button.

8 Remove dishes from the appliance

- When the dishwasher is off, open the door and wait about 15 minutes before removing the dishes. This will also facilitate the drying process. Hot dishes are more susceptible to cracking.








9 Features and components

- Spray arms
- Cutlery basket
- Upper basket
- Inner tube
- Lower basket
- Salt container
- Detergent dispenser
- Mugs and cups shelves
- Main filter
- Water supply hose connection
- Water drain hose
- Regulator



NOTE: Figures are for illustrative purposes only Individual models may vary.

TABLE OF WASH PROGRAMMES: EGSP 566 100 E

ITEM	Programme name	The default temperature [°C]	Type of soil	Soil level	Amount of detergent	Type of cycle							Duration [min.] *	Power consumption [kWh] *	Water consumption [litres] *
1	Auto 	55-65°	For lightly, normally or heavily soiled crockery with or without dried-on food.	Normal soil	4g/18g	Pre-wash 45°C	Autowash 55-65°C	Rinse	Rinse 50-55°C	Dry			85-150	1.050-1.551	10.6-15.9
2	Intensive 	60°	Heavily soiled dishes with dried food residue	Normal soil	4g/18g	Pre-wash 50°C	Wash 60°C	Rinse	Rinse	Rinse 70°C	Dry		205	1.651	16.5
3	Hygiene 	70°	With the Sanitize option selected, the water temperature is increased to 70 °C for high temperature sanitization.	Normal soil	4g/18g	Pre-wash 50°C	Wash 70°C	Rinse	Rinse 70°C	Dry			200	1.772	16.5
4	**ECO 	45°	Lightly soiled glass-ware and porcelain	Light soil	4g/18g	Pre-wash	Wash 45°C	Rinse 65°C	Dry				198	0.849	10.0
5	Glass 	50°	For lightly soiled crockery and glass.	Light soil	4g/18g	Pre-wash 40°C	Wash 50°C	Rinse	Rinse 50°C	Dry			120	0.902	13.5
6	1 Hour 	55°	For normally soiled loads that need quick wash.	Light soil	22g	Wash 55°C	Rinse	Rinse 50°C	Dry				60	0.853	11.5
7	Rapid 	40°	Short rinse for slightly soiled dishes without drying	Light soil	12g	Wash 40°C	Rinse 40°C	Rinse 55°C					30	0.781	11.0

** Standard programme This is a reference program for research institutes. Tests according to EN 60436.
This programme is suitable for washing normally soiled tableware. This is the most effective programme taking into account the total energy and water consumption for this kind of tableware.

* Programme duration, energy and water consumption value given in the table have been determined under laboratory conditions. Actual values can vary.