


N

Dishwasher / User Manual



#### Thank you for choosing this product.

This user manual contains important information on safety and instructions intended to assist you in the operation and maintenance of your appliance.

Please take the time to read this user manual before using your appliance and keep this book for future reference.

Icon	Туре	Meaning
	WARNING	Serious injury or death risk
	RISK OF ELECTRIC SHOCK	Dangerous voltage risk
	FIRE	Warning; Risk of fire / flammable materials
$\triangle$	CAUTION	Injury or property damage risk
0	IMPORTANT	Operating the system correctly

# CONTENTS

1 SAFETY INSTRUCTIONS	4
1.1 General Safety Warnings	
1.2 Installation Warnings	5
1.3 During Usage	6
2 INSTALLATION	9
2.1 Machine Positioning	9
2.2 Water Connection	9
2.3 Water Inlet Hose	
2.4 Drain Hose (Model Depending)	
2.5 Electrical Connection	
2.6 Fitting the Machine Undercounter	
3 TECHNICAL SPECIFICATIONS	
3.1 General Sppearance	
3.2 Technical Specifications	
4 BEFORE USING THE APPLIANCE	16
4.1 Preparing Your Dishwasher For First Use	16
4.2 Salt Usage (IF AVAILABLE)	
4.3 Fill The Salt (IF AVAILABLE)	
4.4 Test Strip	
4.5 Water Hardness Table	
4.6 Water Softener System	
4.7 Setting	
4.8 Detergent Usage	
4.9 Filling The Detergent	
4.10 Using Combined Detergents	
4.11 Rinse-aid Usage	
4.12 Filling The Rinse-aid And Setting	
5 LOADING YOUR DISHWASHER	
5.1 Recommendations	
5.2 Alternative Basket Loads	
6 PROGRAMME TABLE	25
7 THE CONTROL PANEL	27
7.1 Changing a Programme	28
7.2 Cancelling a Programme	
7.3 Switching The Machine Off	29
8 CLEANING AND MAINTENANCE	31
8.1 Filters	31
8.2 Spray Arms	
8.3 Drain Pump	32
9 TROUBLESHOOTING	33

# **1 SAFETY INSTRUCTIONS**

# 1.1 General Safety Warnings

• Read these instructions carefully before using your appliance and keep this manual for future reference.

Please check the packaging of your machine before installation and the outer surface of the machine once the packaging has been removed. Do not operate the machine if it appears damaged or if the packaging has been opened.

 Packaging materials protect your machine from any damage that might occur during transportation. The packaging materials are environmentally friendly as they are recyclable. Use of recycled material reduces raw material consumption and decreases waste production.

This appliance can be used by children aged from 8 years and above, and by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand hazards involved. Children should not be allowed to play with the appliance.

A Remove packaging and keep it out of reach of children.

A Keep children away from detergents and rinse aids.

✓ There may be some residue left in the machine after washing. Keep children away from the machine when it is open.

# **1.2 Installation Warnings**

- Choose a suitable and safe place to install your machine.
- Only original spare parts should be used with the machine

 $\wedge$  Unplug the machine before installation.

⚠️ Your machine must only be installed by an authorised service agent. Installation by anyone other than an authorised agent may cause your warranty to be void.

Check that the indoor electrical fuse system is connected in line with safety regulations.

All electrical connections must match the values on the plate.

A / Ensure the machine does not stand on the electrical supply cable.

Never use an extension cord or a multiple socket connection

/!\ The plug should be accessible after the machine is installed

 After installation, run your machine unloaded for the first time.

 $\bigwedge$   $\bigwedge$  The machine must not be plugged in during positioning.

Always use the coated plug supplied with your machine.

If the electrical cable is damaged, it should only be replaced by a qualified electrician.

 Connect the hose directly to the water inlet tap. The pressure supplied by the tap should be a minimum of 0.03 MPa and a maximum of 1 MPa. If the pressure exceeds 1 MPa, a pressure relief valve must be fitted between the connection.

# 1.3 During Usage

• This machine is for domestic use only; do not use it for other purposes. Commercial use will void the guarantee.

<u>/i</u>Do not stand, sit or place loads on the open door the dishwasher.

⚠Only use detergents and rinse aids produced specifically for dishwashers. Our company is not responsible for any damage that may occur due to misuse.

 $\triangle$  Do not drink water from the machine.

• Due to the danger of explosion, do not place any chemical dissolving agents into the machine's washing section.

• Check the heat-resistance of plastic items before washing them in the machine.

⚠Only put items in the machine which are suitable for dishwashing, and take care not to overfill the baskets.

⚠️Do not open the door while the machine is in operation, hot water may spill out. Safety devices ensure the machine stops if the door is opened.

The machine door should not be left open. It may cause accidents.

Place knives and other sharp objects in the cutlery basket in a blade-down position.

For models with the automatic door-opening system, when the EnergySave option is active, the door will open at the end of a program. To prevent damage to your dishwasher, do not attempt to close the door for one minute after it has opened. For effective drying, keep the door open for 30 minutes after a programme has ended. Do not stand in front of the door after the auto-open signal sounds.

In the case of a malfunction, repair should only be performed by an authorised service company, otherwise the warranty will be void.

Before repair work, the machine should be disconnected from the mains. Do not pull the cable to unplug the machine. Switch off the water tap.

Operation at a low voltage will cause a decline in performance levels.

A For safety, disconnect the plug once a program has finished.

To avoid an electric shock, do not unplug the machine with wet hands.

Pull the plug to disconnect the machine from the mains, never pull on the cord.

## **2 INSTALLATION**

#### 2.1 Machine Positioning

When positioning the machine, place it in an area where dishes can be easily loaded and unloaded. Do not put the machine in an area where the ambient temperature falls below 0°C.

Read all warnings located on the packaging before removing the packaging and positioning the machine.

Place the machine close to a water tap and drain. Take into consideration that the connections will not be altered once the machine is in position.

Do not hold the machine by its door or panel.

Leave an adequate distance around the machine to allow ease of movement when cleaning.

Ensure the water inlet and outlet hoses are not squeezed or trapped and that the machine does not stand on the electrical cable while positioning.

Adjust the feet so the machine is level and balanced. The machine should be placed on flat ground otherwise it will be unstable and the door of the machine will not close properly.


Please install the decorative panel as indicated on the assembly sheet. Otherwise, the door may not open properly and steam leakage problem may occur.

#### 2.2 Water Connection

We recommend fitting a filter to your water inlet supply in order to prevent damage to your machine due to contamination (sand, rust, etc.) from indoor plumbing. This will also help prevent yellowing and deposit formation after washing.

Note printing on the water inlet hose! If models are marked with 25°, the water temperature may be max. 25 °C (cold water). For all other models: Cold water preferred; hot water max. temperature 60 °C.

#### 2.3 Water Inlet Hose




**WARNING:** Use the new water inlet hose supplied with your machine, do not use an old machine's hose.

/! WARNING: Run water through the new hose before connecting.


**WARNING:** Connect the hose directly to the water inlet tap. The pressure supplied by the tap should be a minimum of 0.03 MPa and a maximum of 1 MPa. If the pressure exceeds 1 MPa, a pressure relief valve must be fitted between the connection.

WARNING: After the connections are made, turn the tap on fully and check for water leaks. Always turn off the water inlet tap after a wash program has finished.




An Aquastop water spout is available with some models. Do not damage it or allow it to become kinked or twisted.

#### 2.4 Drain Hose (Model Depending)



Connect the water drain hose directly to water drain hole or to the sink outlet spigot. This connection should be minimum 50 cm and maximum 110 cm from floor that dishwasher is placed.

**IMPORTANT:** Items will not wash properly if a drain hose longer than 4 m is used.



#### 2.5 Electrical Connection

**WARNING:** Your machine is set to operate at 220-240 V. If the mains voltage supply to your machine is 110 V, connect a transformer of 110/220 V and 3000 W between the electrical connection.


Connect the product to a grounded outlet protected by a fuse complying with the values in the "Technical Specifications" table".


The earthed plug of the machine must be connected to an earthed outlet supplied by suitable voltage and current.


In the absence of earthing installation, an authorised electrician should carry out an earthing installation. In the case of use without earthing installed, we will not be responsible for any loss of use that may occur.

A line of the second se


#### 2.6 Fitting the Machine Undercounter









EN - 11





EN - 13

## **3 TECHNICAL SPECIFICATIONS**





#### 3.1 General Sppearance

- 1. Upper basket with racks
- 2. Upper spray arm
- 3. Lower basket
- 4. Lower spray arm
- 5. Filters
- 6. Rating plate
- 7. Control panel
- 8. Detergent and rinse-aid dispenser
- 9. Cutlery basket
- 10. Salt dispenser
- 11. Upper basket track latch

**12. Turbo Drying Unit:** This system enhances the drying performance of your dishes.

#### **3.2 Technical Specifications**

Capacity	15 place settings
Dimensions Height Width Depth	820-870 (mm) 598 (mm) 570 (mm)
Net weight	42 kg
Operating voltage / frequency	220-240V 50 Hz
Total current	10(A)
Total power	1900(W)
Water supply pressure	Maximum: 1 (Mpa) Minimum: 0.03 (Mpa)

#### RECYCLING

- Some machine components and packaging consist of recyclable materials.
- Plastics are marked with the international abbreviations:(>PE<, >PP<, etc.)</li>
- The cardboard parts consist of recycled paper. They can be put into waste paper containers for recycling.
- Material unsuitable for domestic waste must be disposed of at recycling centres.
- Contact a relevant recycling centre to obtain information about disposal of different materials.

#### PACKAGING AND THE ENVIRONMENT

 Packaging materials protect your machine from damage that may occur during transportation. The packaging materials are environmentally friendly as they are recyclable. The use of recycled material reduces raw material consumption and therefore decreases waste production.

#### **CE Declaration of Conformity**

We declare that our products meet the applicable European Directives, Decisions and Regulations and the requirements listed in the standards referenced.

#### **Disposal of Your Old Machine**



The symbol on the product or on its packaging indicates that this product may not be treated as household waste. Instead, it shall be taken to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring

this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about recycling this product, please contact your local city office, your household waste disposal service or the shop where the product was purchased.

# 4 BEFORE USING THE APPLIANCE

# 4.1 Preparing Your Dishwasher For First Use

- Make sure the electricity and supply water specifications match the values indicated in the installation instructions for the machine.
- Remove all packaging material inside the machine.
- · Set the water softener level.
- Fill the rinse aid compartment..


#### 4.2 Salt Usage (IF AVAILABLE)

For a good washing function, the dishwasher needs soft. i.e. less calcareous water. Otherwise. White lime residues will remain on the dishes and the interior equipment. This will negatively affect your machine's washing, drying and shining performance. When water flows through the softener system, the ions forming the hardness are removed from the water and the water reaches the softness required to obtain the best washing result. Depending on the level of hardness of the inflowing water. these ions that harden the water accumulate rapidly inside the softener system. Therefore, the softener system has to be refreshed so that it operates with the same performance also during the next wash. For this purpose, dishwasher salt is used.

Machine can only be used by special dishwasher salt to soften the water. Do not use any small grained or powdered type of salts which can easily soluble. Using any other type of salt can damage your machine.

#### 4.3 Fill The Salt (IF AVAILABLE)

To add softener salt, open the salt compartment cap by turning it counter clockwise. (1) (2) At first use, fill the compartment with 1 kg salt and water (3) until it is almost overflowing. If available, using a funnel (4) will make filling easier. Replace the cap and close it. After every 20-30 Cycles add salt into your machine until it fills up (approx. 1 kg).



# Only add water to the salt compartment on first use.

Use softener salt specifically produced for use in dishwashers.

When you start your dishwasher, the salt compartment is filled with water, therefore put the softener salt in prior to starting your machine.

If the softener salt has overflowed and you do not start the machine immediately, run a short washing program to protect your machine against corrosion.

#### 4.4 Test Strip

Run water through the tap (1min.)	Keep the strip in the water (1sec)	Shake the strip.	Wait (1min.)	Set the hardness level of your machine.
1 munite			1 munite	1 2   2 3   4 5   5 5

**NOTE:** The level is set to 3 as default. If the water is well water or has a hardness level above 90 dF, we recommend that you use filter and refinement devices.

#### 4.5 Water Hardness Table

Level	German dH	French dF	British dE	Indicator
1	0-5	0-9	0-6	L1 is seen on the display.
2	6-11	10-20	7-14	L2 is seen on the display.
3	12-17	21-30	15-21	L3 is seen on the display.
4	18-22	31-40	22-28	L4 is seen on the display.
5	23-31	41-55	29-39	L5 is seen on the display.
6	32-50	56-90	40-63	L6 is seen on the display.

#### 4.6 Water Softener System

The dishwasher is equipped with a water softener which reduces the hardness in the mains water supply. To find out the hardness level of your tap water, contact your water company or use the test strip (if available).

#### 4.7 Setting

- Turn the machine on by pressing the On/Off button.
- Press the Program button for at least 3 seconds immediately after the machine is turned on.
- Release the Program button when "SL" is shown. Next, the last setting level is displayed.
- Press the program button to set the desired level. Each press of the program button increases the level. Once level 6 has been reached, the next press returns the level to 1.
- The last selected water hardness level is stored in the memory by turning the machine off with the On/Off button.

#### 4.8 Detergent Usage

Only use detergents specifically designed for domestic dishwashers. Keep your detergents in cool, dry places out of reach of children.

Add the proper detergent for the selected program to ensure the best performance. The amount of detergent needed depends on the cycle, load size, and soil level of dishes.

Do not fill detergent into the detergent compartment more than required; otherwise you can see whitish streaks or bluish layers on glass and dishes and may cause glass corrosion. Continued use of too much detergent may cause machine damage. Using little detergent can result in poor cleaning and you can see whitish streaksin hard water.


See the detergent manufacturer's instructions for a further information.

#### 4.9 Filling The Detergent

Push the latch to open the dispenser and pour in the detergent.

Close the lid and press it until it locks in place. The dispenser should be refilled just before the start of each programme. If the dishes are heavily soiled, place additional detergent in the pre-wash detergent chamber.





## 4.10 Using Combined Detergents

These products should be used according to the manufacturer's instructions. Never put combined detergents into the interior section or the cutlery basket. Combined detergents contain not only the detergent but also rinse-aid, salt replacement substances and additional components depending on the combination. We recommend you do not use combined detergents in short programmes. Please use powder detergents instead.

If you encounter problems when using combined detergents, please contact the detergent manufacturer.

When you stop using combined detergents, make sure that water hardness and rinse aid settings are set to the correct level.

#### 4.11 Rinse-aid Usage

The rinse aid helps to dry the dishes without streaks and stains. Rinse-aid is required for stain-free utensils and clear glasses. The rinse aid is automatically released during the hot rinse phase. If rinse aid dosage setting set too low, whitish stains remains on dishes and dishes do not dry and washed clean.

If rinse aid dosage setting set too height, you can see bluish layers on glass and dishes.

#### 4.12 Filling The Rinse-aid And Setting

To fill the rinse aid compartment, open the rinse-aid compartment cap. Fill the compartment with rinse aid to the MAX level and then close the cap. Be careful not to overfill the rinse aid compartment and wipe up any spills.

#### In order to change the rinse aid level, follow the below steps before turning on the machine:

- Turn on the machine by pressing the On/ Off button.
- Press the Programme button for at least 5 seconds immediately after the machine is turned on.
- Release the Programme button when "rA" is shown. Rinse aid level setting follows water hardness level setting. Next, the last setting level is displayed.
- Set the level by pushing the programme button.
- Switch off the machine to save the setting.
- The factory setting is "4".

If the dishes are not drying properly or are spotted, increase the level. If blue stains form on your dishes, decrease the level.





Level	Brightener Dose	Indicator
1	Rinse-aid not dispensed	r1 is shown on the display.
2	1 dose is dispensed	r2 is shown on the display.
3	2 doses are dispensed	r3 is shown on the display.
4	3 doses are dispensed	r4 is shown on the display.
5	4 doses are dispensed	r5 is shown on the display.

## **5 LOADING YOUR DISHWASHER**

For best results, follow these loading guidelines.

Loading the household dishwasher up to the capacity indicated by the manufacturer will contribute to energy and water savings. Manual pre-rinsing of tableware items leads to increased water and energy consumption and is not recommended You can place cups, glasses, stemware, small plates, bowls, etc. in upper basket. Do not lean long glasses against one another or they cannot remain steady and may receive damage. When placing long stem glasses and goblets, lean them against the basket edge or rack and not against other items.

Place all containers such as cups, glasses and pots into the dishwasher with the opening facing downwards otherwise water can collect on items.

If there is cutlery basket in machine, you are recommended to use the cutlery grid in order to obtain the best result. Place all large (pots, pans, lids, plates, bowls etc.) and very dirty items in the lower rack. Dishes and cutlery should not be placed above each other.

**WARNING:** Take care not to obstruct the rotation of spray arms.

**WARNING:**Make sure after loading the dishes do not prevent opening the detergent dispenser.

#### 5.1 Recommendations

Remove any coarse residue on dishes before placing the dishes in the machine. Start the machine with full load.





Do not overload the drawers or place dishes in the wrong basket.

**WARNING:** To avoid any possible injuries, place long-handle and sharp-pointed knives with their sharp points facing down or horizontally on the baskets.

### Four Folding Racks


The folding racks allow easier placement of larger items, such as pots and pans. Each section can be folded separately. The racks can be raised up, or folded down, as shown in the images.






#### **Height Adjustment**

The upper basket includes a mechanism which enables the height of the basket to be adjusted up (1) or down (2) without having to remove the basket. Hold the basket on both sides and pull it up or push it down, ensuring both sides of the upper basket are in the same position.



#### Height Adjustable Rack (peg type)

The foldable racks in the upper basket enable the placement of large items such as pots and pans. Each section can be folded separately. The foldable racks can be either raised up or folded down.



#### **Upper Cutlery Basket**

The upper cutlery basket is designed for you to place forks, spoons and knives, long dippers and small items.



The Upper Cutlery Basket is composed of three pieces; if you need to space for the dishes in the upper basket, you can slide the left or right part of the upper cutlery basket in order to obtain more space.



The middle part of the upper basket can be movable down and up to obtain more space.




**WARNING:** Knives and other sharp objects must be placed horizontally in the cutlery basket.




#### **Bottle Rack**


The bottle rack can be used to wash large open containers, such as bowls, pans, or tupperware, as well as items that are tall, such as jugs. The bottle rack can be pulled out in the direction of the arrow, as shown below.





#### **Multi-functional Rack System**

The multi-functional rack system is located in the lower basket. It can be used for the placement of mugs or large utensils for washing.










To close the racks, fold them from position (a) to position (b). Make sure the clips on the rack fit on the wire (c). The reverse method can be used to open the racks. The racks in the multi-functional rack system have two positions; the lower position (d) and the upper position (e). Take care to fix the racks correctly (f) onto the wire. Do not place items in contact with the spray arm.




#### 5.2 Alternative Basket Loads

#### Lower Basket




#### Top Basket




#### Incorrect Loads

Incorrect loading can cause poor washing and drying performance. Please follow the manufacturer's recommendations for a good performans result.










			⊳				
Water consumption (I/cycle)	Electiricity consumption (kWh/ cycle)	Program Duration (h:min)	Amount of Detergent: A: 25 cm3 B: 15 cm3"	Level of Soil:	Type of Soil:	Program Name:	
6.6	0.340	00:14	В	Light	Fastest program for lightly soiled and recently used dishes and suitable for 4 place settings.	Jetwash 14'	P1
10.9	0.650	00:30	A	Light	Suitable for lightly soiled dishes and quick wash.	Quick 30'	P2
9.0	0.861	04:30	A	Medium	Standard program for normally soiled daily using dishes with reduced energy and water consumptions.	Eco	P3
15.4	1.600	01:53	A	Неаvy	Suitable for both lightly solled delicate glassware on upper rack and heavily solled crockery on lower rack.	MixWash+	P4
9.5	1.000	00:50	A	Medium	Suitable for normally solied daily dishes with faster program.	Quick & Clean	P5
10.6 - 17.7	0.650 - 0.850	01:12 - 01:31	A	Medium	Auto program for normally soiled delicate dishes.	Smart 30°C - 50°C	P6
11.8 - 24	1.250 - 1.900	02:59 - 01:49	A	Неаvy	Auto program for normally soiled dishes.	Smart 50°C - 70°C	P7
20.3	1.750	02:41	A	Heavy	Suitable for heavily solied dishes with effective cleaning by steam.	Steam Wash	P8

6 PROGRAMME TABLE

- The program duration may change according to the amount of dishes, the water temperature, the ambient temperature and selected additional functions.
- Values given for programmes other than the eco programme are indicative only.
- Eco programme is suitable to clean normally soiled tableware, that for this use, it is the most efficient programme in terms of its combined energy and water consumption, and that it is used to assess compliance with the EU ecodesign legislation.
- Washing tableware in a household dishwasher usually consumes less energy and water in the use phase than hand dishwashing when the household dishwasher is used according to the manufacturer's instructions.
- Only use powder detergent for short programs.
- Short programs do not include drying.
- To assist drying, we recommend slightly opening the door after a cycle is complete.
- You can access the product database where the model information is stored by reading the QR code on the energy label.

**NOTE:** According to regulations 1016/2010 and 1059/2010, Eco program energy consumption values may differ. This table is in line with regulations 2019/2022 and 2017/2022.

## 7 THE CONTROL PANEL



- 1. On/Off Button
- 2. Program Selection Button
- 2.1. Program Indicators
- 3. Delay Button
- 3.1. Delay Indicator
- 4. Remaining Time Indicator
- 5. Start/Pause Button
- 6. Options Button
- 7. Select Button
- 8. Salt Indicator
- 9. Rinse Aid Indicator
- 10. Tablet Indicator
- 11. Extra Hygiene Indicator
- 12. Half Load Indicators
- 13. Extra Drying Indicator
- 14. Extra Fast Indicator
- 15. Extra Silent Indicator
- 16. Washing Step Indicators
- a- Washing Step Indicator
- b- Rinse Step Indicator
- c- Drying Step Indicator
- d- End Step Indicator

#### 1. On/Off Button

Turn the machine on by pressing the On/Off button.

#### 2. Program Selection Button

Select a suitable programme by pressing the Programme button. The selected program indicator (2.1) will be on. For the details of the programs refer to section Program Table.

#### 3. Delay Button

You can delay the start time of the programme for 1-2...24 hours by pressing the delay button (3) before the programme starts. The delay indicator (3.1) will be on. If you want to change the delay time, first press the Start/Pause button and then the delay button to select a new delay time. To activate the new delay time, press the Start/Pause button. To cancel the delay, you need to switch to 0 hour by using the delay when the machine is paused.

#### 4. Remaining Time Indicator

Programme flow can be monitored via the Wash,Rinse, Dry, End indicators and Remaining Time Indicator.

#### 5. Start/Pause Button

Press the Start/Pause button to start the programme. The wash lamp turns on and the Remaining Time Indicator shows the programme duration. It also indicates the remaining time during the programme flow. If you open the door of your machine when the programme is running the duration of the programme pauses, and related washing step indicator blinks.

#### 6. Options Button

Options can be selected by pressing the Options button repeatedly. The chosen option will be indicated by a blinking LED.

#### 7. Select Button

Select the option by pressing the Select button. The LED for the chosen option will then remain lit.

#### 8. Salt Indicator

When there is insufficient softening salt, the salt lack warning indicator turns on and you should fill up the salt chamber.

#### 9. Rinse Aid Indicator

When the rinse aid level is low, the rinse aid lack warning indicator turns on and you should fill the rinse aid chamber.

#### 10. Tablet Indicator

Select the Tablet Detergent function when using a combined detergent that contains salt, rinse aid or other extras. The Tablet Detergent Indicator will remain on for as long as it is selected.

#### 11. Extra Hygiene Indicator

Select the Extra Hygiene function to increase the wash temperature, for a maximum hygiene washing operation. The Extra Hygiene Indicator will illuminate.

#### 12. Half Load Indicator

Select the Half Load function to choose which area of the dishwasher contains dishes to be washed. You can select both baskets, the upper basket only, or the lower basket only. Press the button until the indicator corresponding to the basket containing the dishes to be washed illuminates. The Half Load Indicator will illuminate while this function is in operation. Dishes placed in other areas will not be washed.

#### 13. Extra Drying Indicator

If Extra Drying option is selected, extra heating and drying steps will be added into the selected program, so you can ensure that your dishes will be extracted dryer.

#### 14. Extra Fast Indicator

Select the Extra Fast function to decrease the duration of a programme, providing more economical water usage. The Extra Fast Indicator will illuminate.

#### 15. Extra Silent Indicator

Select the Extra Silent function for a more sensitive and silent washing operation. The Extra Silent Indicator will illuminate. This option reduces the sound pressure level of the washing.

#### 16. Washing Step Indicators

The display will show the indicator corresponding to the status of the programme in operation. While the Drying indicator is on, the machine will remain silent with respect to the programme you have selected for 15 to 100 minutes.

- \* Wash
- \* Rinse
- \* Dry
- \* End


**NOTE:** Child lock is activated/deactivated by pressing select button (7) for about 3 seconds. When it is activated, all leds blink and "CL" is shown on Remaning Time Indicator (4) once. When it is deactivated, all leds and "CL" blink twice.

**ONOTE**: If you switch the machine to off position after selecting the delay time and the programme has started, the delayed time is cancelled.


**W**NOTE: To save any program as favourite program, press program selection (2) and delay (3) buttons at the same time. To select favourite program, press program selection button (2) for 3 seconds.

#### Changing a programme

If you would like to change the programme when the machine is already running.










#### Cancelling a programme

If you would like to cancel a programme when it is running.





### Switching the Machine Off



**UNOTE:** Do not open the door before the programme ends.

**ONOTE:** At the end of washing programme, you can leave the door of your machine ajar to hasten the drying.

**CNOTE:** If the door of machine is opened or power is cut off during washing the programme will continue when the door is closed or the power is restored.

# Buzzer Sound Control (Model Depending)

To change the buzzer sound level, follow the below steps:

**1.** Open the door and press Option (6) and Select (7) buttons at the same time for 3 seconds.

 When sound setting is recognized, buzzer gives a long sound and machine will display last set level, from "S0" to "S3".
To decrease sound level press Select

button (7). To increase sound level, press Options button (6).

**4.** To save the selected sound level, turn off the machine.

"S0" level means all voices are off. Factory setting is "S3".

#### Save Power Mode

To activate or deactivate save power mode, follow the below steps:

**1.** Open the door and press Program (2) and Option (6) buttons at the same time for 3 seconds.

**2.** After 3 seconds, the machine will display last Setting, "IL1" or "IL0".

**3.** When Save Power Mode is activated, "IL1" will be displayed. On this mode, interior lights (if avaliable) will turn off 2 minutes after the door is opened, and the machine will turn off 15 minutes after any intervention in order to save energy.

4. When Save Power Mode is deactivated "IL0" will be displayed. If Save Power Mode is deactive, interior lights will be on as long as the door is open, and the machine will always be on unless it is turned off by user. 5. To save the selected setting, turn off the machine.

In factory setting, Save Power Mode is active.

#### Natural Ion Tech (Model Depending)

This function provides extra hygiene to the machine thanks to lon Technology. It operates as an independent program. This function is activated by pressing Options button (6) for 3 seconds in ready state. At the end of 3 seconds, "Ion" will be displayed which indicates that Natural Ion Tech function is activated. The button is released after "Ion" is displayed. If there is no intervention by user, 24 hours after activation of Natural Ion Tech function, it is automatically cancelled. **UNOTE:** If machine is turned off, Natural Ion Tech function is cancelled.

**UNOTE:** Natural Ion Tech function does not work with any program.

#### Crystalight (Model Depending)

This technology which have lon and Light Technology together, provides to extra hygiene. It prevents bad odor during a washing program that includes a drying step. Crystalight function is activated or deactivated before starting program by pressing Options button (6) for 6 seconds. At the end of 6 seconds, "U1" will be displayed which indicates Crystalight function is activated. When it is deactivated, at the end of 6 seconds, "U0" will be displayed. Crystalight setting follows Natural Ion Tech setting. Default set is "UO".

**UNOTE:** If user do not deactivate Crystalight function at the end of program, it will remain active until the machine turns off.

**CNOTE:** If Crystalight or Natural Ion Tech function is active, Natural Ion Tech warning led lights up like dimming during door is open.

## 8 CLEANING AND MAINTENANCE

Cleaning your dishwasher is important to maintain the machine's service life Make sure that the water softening setting (If available) is done correctly and correct amount of detergent is used to prevent limescale accumulation. Refill the salt compartment when the salt sensor light comes on.Oil and limescale may build up in your Dishwasher over time. If this occurs:

- Fill the detergent compartment but do not load any dishes. Select a programme which runs at high temperature and run the Dishwasher empty. If this does not clean your Dishwasher sufficiently, use a cleaning agent designed for use with dishwashers.
- To extend the life of your dishwasher, clean the appliance regularly on each month
- Wipe the door seals regularly with a damp cloth to remove any accumulated residue or foreign objects.

#### 8.1 Filters

Clean the filters and spray arms at least once a week. If any food waste remains or foreign objects on the coarse and fine filters, remove them and clean them thoroughly with water.


- a) Micro Filter b) Coarse Filterc) Metal Filter

To remove and clean the filter combination, turn it counter clockwise and remove it by lifting it upwards (1).Pull the coarse filter out of the micro filter (2).Then pull and remove the metal filter (3).Rinse the filter with lots of water until it is free of residue. Reassemble the filters. Replace the filter insert, and rotate it clockwise (4).

- Never use your dishwasher without a filter.
- Incorrect fitting of the filter will reduce the washing effectiveness.
- Clean filters are necessary for proper running of the machine.

#### 8.2 Spray Arms

Make sure that the spray holes are not clogged and that no food waste or foreign object is stuck to the spray arms. If there is any clogging, remove the spray arms and clean them under water. To remove the upper spray arm undo the nut holding it in position by turning it clockwise and pulling it downwards. Make sure that the nut is properly tightened when refitting the upper spray arm.



#### 8.3 Drain Pump

Large food residues or foreign objects which were not captured by the filters may block the waste water pump. The rinsing water will then be above the filter.

## Warning Risk of cuts!

When cleaning the waste water pump, ensure that you do not injure yourself on p ieces of broken glass or pointed implements.

In this case:

**1.** First always disconnect the appliance from the power supply.

- 2. Take out baskets.
- 3. Remove the filters.

**4.** Scoop out water, use a sponge if required.

**5.**Check the area and remove any foreign objects.

6. Install filters.

7. Re-insert baskets.

## 9 TROUBLESHOOTING

FAULT	POSSIBLE CAUSE	TROUBLESHOOTING
	Your Dishwasher is not plugged in.	Plug your Dishwasher in.
	Your Dishwasher is not switched on.	Switch your Dishwasher on by pressing the On/Off button.
The programme does	Fuse blown.	Check your indoor fuses.
not start.	Water inlet tap is closed.	Turn on the water inlet tap.
	Your Dishwasher door is open.	Close the Dishwasher door.
	Water inlet hose and machine filters are clogged.	Check the water inlet hose and machine filters and make sure they are not clogged.
	Water drain hose is clogged or twisted.	Check the drain hose, then either clean or untwist it.
Water remains inside the machine.	The filters are clogged.	Clean the filters.
	The programme is not finished yet.	Wait until the programme is finished.
Machine stops during	Power failure.	Check mains power.
washing.	Water inlet failure.	Check water tap.
Shaking and hitting noises are heard during a wash operation.	The spray arm is hitting the dishes in the lower basket.	Move or remove items blocking the spray arm.
	Dishes placed incorrectly, sprayed water not reaching affected dishes.	Do not overload baskets.
	Dishes leaning each another.	Place dishes as instructed in the section on loading your dishwasher.
Partial food wastes	Not enough detergent used.	Use the correct amount of detergent, as instructed in the programme table.
remain on the dishes.	Wrong wash programme selected.	Use the information in the programme table to select the most appropriate programme.
	Spray arms clogged with food waste.	Clean the holes in the spray arms with thin objects.
	Filters or water drain pump clogged or filter misplaced.	Check the drain hose and filters are correctly fitted.

FAULT	POSSIBLE CAUSE	TROUBLESHOOTING
	Not enough detergent used.	Use the correct amount of detergent, as instructed in the programme table.
Whitish stains remains	Rinse aid dosage and/or water softener setting set too low.	Increase rinse aid and/or water softener level.
on dishes.	High water hardness level.	Increase water softerner level and add salt.
	Salt compartment cap not closed properly.	Check that the salt compartment cap is closed properly.
	Drying option is not selected.	Select a programme with a drying option.
Dishes do not dry.	Rinse aid dosage set too low.	Increase rinse aid dosage setting.
	Stainless-steel quality of the dishes is insufficient.	Use only dishwasher-proof sets.
	High level of salt in wash water.	Adjust the water hardness level using water hardness table.
Rust stains form on the dishes.	Salt compartment cap not closed properly.	Check that the salt compartment cap is closed properly.
	Too much salt spilled in the Dishwasher while filling it with salt.	Use funnel while filling salt to the compartment to avoid spillage.
	A poor mains grounding.	Consult a qualified electrician immediately.
Detergent remains in the detergent compartment.	Detergent was added when the detergent compartment was wet.	Make sure detergent compartment is dry before use.

#### AUTOMATIC FAULT WARNINGS AND WHAT TO DO

TROUBLE CODE	POSSIBLE FAULT	WHAT TO DO
		Make sure the water inlet tap is open and water is flowing.
FF	Water inlet system failure	Separate the inlet hose from the tap and clean the filter of the hose.
		Contact for service if the error continues.
F5	Pressure system failure	Contact for service.
F3	Continuous water input	Close the tap and contact for service.
	Inability to discharge water	Water discharge hose and filters may be clogged.
F2		Cancel the program.
		If the error continues, contact for service.
F8	Heater error	Contact for service.
F1	Overflow	Unplug the machine and close the tap.
	Overnow	Contact for service.
FE	Faulty electronic card	Contact for service.
F7	Overheating	Contact for service.
F9	Diverter position error	Contact for service.
F6	Faulty heater sensor	Contact for service.
н	High voltage failure	Contact for service.
LO	Low voltage failure	Contact for service.

The installation and repairing procedures should always carried out by the Authorised Service Agent in order to avoid possible risks. The manufacturer shall not be held liable for damages that may arise from procedures carried out by unauthorised persons. Repairs may be carried out by technicians only. If a component has to be replaced, ensure that only original spare parts are used.

Improper repairs or use of non-original spare parts may cause considerable damage and put the user at considerable risk.

Contact information for your customer service can be found on the back of this document. Function-relevant genuine spare parts according to the corresponding Ecodesign order can be obtained from Customer Service for a period of at least 10 years from the date on which your appliance was placed on the market within the European Economic Area.

NO: Gram A/S Tel.: 22 07 26 30 www.gram.no **SE: Gram A/S** Tel.: 040 38 08 40 www.gram.se **FI: Gram A/S** Tel.: 020 7756 350 www.gram.fi

Gram A/S . Gejlhavegård 2B . DK-6000 Kolding . +45 73 20 10 00 . www.gram.dk





52178629 R22